Excellence Industries

Profit from the Power of Partnership.

DIRECTIONS

CTF Countertop Freezer

INSTRUCTIONS





CAUTION FLAMMABLE REFRIGERANT

– DANGER : Risk Of Fire Or Explosion. Flammable Refrigerant Used. Do Not Use Mechanical Devices To Defrost Refrigerator. Do Not Puncture Refrigerant Tubing.

– DANGER : Risk Of Fire Or Explosion. Flammable Refrigerant Used. To Be Repaired Only By Trained Service Personnel. Do Not Puncture Refrigerant Tubing.

– CAUTION : Risk Of Fire Or Explosion. Flammable Refrigerant Used. Consult Repair Manual/Owner's Guide Before Attempting To Install Or Service This Product. All Safety Precautions Must be Followed.

– CAUTION : Risk Of Fire Or Explosion. Dispose Of Property In Accordance With Federal Or Local Regulations. Flammable Refrigerant Used.

– CAUTION : Risk Of Fire Or Explosion Due To Puncture Of Refrigerant Tubing; Follow Handling Instructions Carefully. Flammable Refrigerant Used.

– CAUTION : Risk Of Fire Or Explosion Due To Flammable Refrigerant Used; Follow Handling Instructions Carefully In Compliance With U.S. Government Regulations.

Safety Caution

– WARNING: Keep ventilation openings, in the appliance enclosure, clear of obstruction.

– WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

– WARNING: Do not damage the refrigerant circuit.

– WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

– WARNING: Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

– WARNING: All component parts shall be replaced with like components and that servicing shall be done by factory authorized service personnel.

– WARNING: Risk Of Fire Or Explosion. Dispose Of Properly In Accordance With Federal Or Local Regulations.

General Instructions

Carefully examine the cabinet for shipping damage before discarding the packing material. If any damage is found, contact the delivery carrier immediately and have their agent prepare an inspection report for the purpose of registering a claim. THIS IS YOUR RESPONSIBILITY.

Positioning

The cabinet should be positioned on a firm, flat base, and must not be exposed to direct heat from radiators, sunlight or other sources of heat. The cabinet emits heat while it is running, and this heat is expelled through the black grating found at the back of the cabinet. Consequently, there must be a gap of at least 10 cm (4'') behind the cabinet. If the cabinet is placed in a recess, placed beneath a working surface, etc., there must be a gap of at least 10 cm behind and above the cabinet. The cabinet must not be placed on the floor.

It is important for the unit to remain upright and not tilted as the oils from the compressor will affect the cooling system. If the unit is tilted, let it stand upright for a full 24 hours prior to plugging the unit in.

Use

Before using the appliance, it should be cleaned thoroughly. A weak solution of soap and water is recommended. Scouring powder must **not** be used.

Once cleaned, setting the temperature is the only operation needed. The temperature can be adjusted by using the thermostat button located at the back of the cabinet. Start by positioning to figure 5 on the thermostat button opposite the hole in the plate. Place a thermometer approximately 10 cm (4'') inside the cabinet on the top shelf and check the temperature once it has reached a stable level. Turn the thermostat button clockwise if the temperature is too high or counter-clockwise if the temperature is too low. Once the cabinet has reached the required temperature, it is ready for use. Do not place products further forward than the front edge of shelves.

If you want to keep the light on, turn on the light switch located at the back of the cabinet.

Note:
This equipment is intended for the storage and display of non-potentially-hazardous packaged ice cream and packaged frozen food.

Electrical Requirements
The power supply to the cabinet must conform to all national and local electrical codes. A separate circuit is recommended for each cabinet to prevent loss of product if another appliance on the same circuit causes supply failure.

Note:
The supply voltage must not vary more than ten percent from that shown on the data plate located on the rear side of the cabinet. If there's any doubt, contact an authorized electrician.

WARNING

- Before removing the plate to the compressor compartment, switch off the appliance and remove the plug from the socket. For your safety, authorized personnel should only service the appliance. The manufacturer refuses to accept responsibility for any injuries or damage sustained due to unauthorized service or alterations to the appliance.
- Closed containers with fluids containing carbon dioxide must **not** be put in the freezer, as they may explode.
- Popsicles or ice lollies must not be consumed immediately after they are taken out, as they may injure the lips.

Maintenance
A layer of frost tends to gradually form inside the cabinet. When the layer is approximately 3 mm (1/8'') thick, it should be scraped off using a plastic scraping tool (usually provided with cabinet), and removed without switching the power off. The cabinet is then ready for use again.

If the inside of the cabinet needs to be cleaned, the power should be switched off at the main switch so the layer of frost can melt before cleaning.

The unit has a condenser that can collect dust. The collection of dust will reduce the ability to transfer and ultimately damage the compressor. The condenser should be cleaned regularly by an authorized service technician.

Breakdown

If the current supply to the cabinet has been disconnected, it should not be reconnected until 6 minutes have passed. Unless the delay is observed, the compressor will not be able to start.

The cabinet has been thoroughly tested prior to dispatch; however, if breakdowns occur, please check the following points before reporting:

1. Is the main current disconnected?
2. Has the fuse blown?
3. Has the main switch been switched on?
4. Is the plug connected correctly?
5. Is the thermostat button set correctly?

Other defects	**Check the following**
Compressor not running	Has it been switched off at the main switch? Has the fuse blown? Is the socket switched on? Is the plug properly in place?
The temperature is too high	Is the thermostat correctly adjusted? Check and adjust as described in “Use” section. Is the frost layer too thick?
The compressor runs continuously	Is the thermostat correctly adjusted? Check and adjust as described in “Use section.” Is the ambient temperature too high? (Ensure there’s ample air circulation around the appliance.)

If you have checked the above points and the appliance is still not working satisfactorily, please contact your authorized service agent.

Replacement of Light
WARNING: Disconnect main current before replacing light.

Destruction
It is the responsibility of the appliance owner to ensure that the destruction of the appliance is carried out in accordance with safety and environmental requirements.

VIZ: Doors shall be removed, and together with any locking device, be destroyed separately from the appliance. An authorized refrigeration engineer shall remove the refrigeration system, and components including refrigerant and compressor oil delivered to a recycling center.

The equipment is intended for use in an area where the environmental conditions are controlled and maintained so that the ambient temperature typically does not exceed 80ºF (27ºC).



Attention réfrigérant inflammable

– Danger: risque d'incendie ou d'explosion. Réfrigérant inflammable utilisé. N'utilisez pas de dispositifs mécaniques pour dégivrer le réfrigérateur. Ne pas perforer le tube réfrigérant.

– Danger: risque d'incendie ou d'explosion. Réfrigérant inflammable utilisé. Être réparé uniquement par un technicien qualifié. Ne pas perforer le tube réfrigérant.

– ATTENTION: risque d'incendie ou d'explosion. Réfrigérant inflammable utilisé. Consulter le manuel de réparation/guide du propriétaire avant d'essayer d'installer ou de réparer ce produit. Toutes les précautions de sécurité doivent être respectées.

– ATTENTION: risque d'incendie ou d'explosion. Disposer de biens conformément aux réglementations fédérales ou locales. Réfrigérant inflammable utilisé.

– ATTENTION: risque d'incendie ou d'explosion dû à la perforation du tube réfrigérant; Suivez attentivement les instructions de manutention. Réfrigérant inflammable utilisé.

– ATTENTION: risque d'incendie ou d'explosion dû à un réfrigérant inflammable utilisé; Suivez attentivement les instructions de manutention conformément avec le gouvernement américain et les réglementations canadiennes.

Sécurité Attention –

- AVERTISSEMENT: Gardez les ouvertures de ventilation de l'appareil boîtier, dégagée de tout obstacle.

- AVERTISSEMENT: ne pas utiliser les périphériques mécaniques ou d'autres moyens d'accélérer le processus du dégivrage, autres que celles recommandées par le fabricant.

- AVERTISSEMENT: ne pas endommager le circuit de fluide réfrigérant.

- AVERTISSEMENT: ne pas utiliser d'appareils électriques dans les compartiments d'entreposage des denrées de l'appareil, sauf s'ils sont du type recommandé par le fabricant.

- AVERTISSEMENT: ne pas stocker substances explosives telles que les bombes aérosol avec un gaz propulseur inflammable dans cet appareil.

- AVERTISSEMENT : Tous les composants doivent être remplacés avec comme les composants et que la réalisation de l'entretien doit être effectué en usine par le personnel de service autorisé.

- AVERTISSEMENT : Risque d'incendie ou d'explosion. Veuillez mettre au rebut conformément au gouvernement fédéral ou **aux réglementations locales.**

Instructions générales
Examinez soigneusement l'armoire afin de déceler d'éventuels dommages dûs au transport avant de vous débarasser de l'emballage. En case de dommages, contactez immédiatement le transporteur et faites établir par l'un de ses agent un rapport d'inspection en vue de l'enregistrement d'une plainte.
CECI RELÈVE DE VOTRE RESPONSABILITÉ.

Installation
Placez l'armoire sur une surface plane et stable. Ne l'exposez pas à la chaleur directe des radiateurs ni à la lumière du soleil ou toute autre source de chaleur directe. L'armoire émet de la chaleur en cours de fonctionnement, chaleur qui est expulsée par la grille noire placée à l'arrière du coffre. Il est par conséquent nécessaire de laisser un intervalle d'au moins 100 mm entre la mur et l'armoire. Il doit en être de même si l'armoire est placé dans une niche ou placée sous une surface de travail. Elle ne doit pas être posée directement sur le sol.

Il est important pour l'unité de rester en position verticale et pas incliné comme les huiles provenant du compresseur aura une incidence sur le système de refroidissement. Si l'appareil est incliné, le laisser se tenir debout pendant 24 heures avant de brancher l'appareil po

Utilisation
Nettoyes l'appareil avant de le mettre en service. Nous vous recommandon d'utilliser une eau lègérement savonneusse. L'utilisation de poudre à récurer est à proscrire.
Le réglage de la température est la seule opération à effectuer. Pour ce faire utilisez le bouton de thermostat placé à l'arrière de l'armoire. Posez un thermometer d'environ 10 cm à l'intériur sur l'étagère supérieure et contrôlez la température lorsqu'elle a atteint un niveau stable. Tournez le bouton de thermostat dans le sens des aiguilles d'une

montre si la température est trop élevée ou dans le sens inverse des aiguilles d'une montre si elle est trop basse.
Cet équipement est destiné au storage et à l'étalage de crême glacée emballée potentiellement non-dangereuse et de nourriture surgelée emballée.

Installations électriques
La puissance utilisée doit être conforme aux normes régionales ou nationales relatives aux installations électriques. L'utillisation de circuits séparés pour chaque armoire est à recommender afin d'éviter toute perte de produit en cas de panne d'alimentation de courant.
Notez que la tension ne doit pas varier de plus de 10% de celle indiquée sur la plaque de signalisation placée à l'arrière de l'armoire.
En cas de doute contectez un électrician agréé.

Advertissement
Avant de retirer la plaque du compartiment du compresseur, éteignez l'appare et débranchez la prise.
Pour des raisons de sécurité l'appareil ne devra être réparé que par des professionels.
Le fabricant décline toute responsabilité quant aux dommages aux personnes ou aux biens occasionnés par des personnes non habilitées ou dûs à la manipulation incorrecte de l'appareil.
Cet appareil ne doit être utilisé que pour le stockage et la présentation pour la mise en vente de produits non dangereux.

ADVERTISSEMENT
N'entreposez pas de récipients clos contenant des fluids à l'oxyde de carbone dans le congélateur; ils pourraient exploser. Les glaces en bâtonnets ne doivent pas être consommés immédiatement à leur sortie du congélature; ells peuvent en effet blesser les lèvres.

Mise en marche
Le réglage de la température est la seule opération à effectuer. Pour ce faire, utilisez le bouton de thermostat placé à l'arriére de l'appareil.
Réglez le bouton du thermostat en le positoinnant sur le chiffre 5 à l'opposé de l'orifice de la plaque. Placez un thermométre d'environ 10 cm dans l'armoire sur l'étagère supérieure et contrôlez la temperature jusqu'à ce qu'elle se soit stabilisée. Tournez le bouton de thermostat dans le sens des aguilles d'une montre si la température est trop élevée ou dans le sens inverse des aguilles d'une montre si elle est trop basse.

Mise en route
Nettoyez l'armoire avant la mise en service. Utilisez dans ce but des produits, nettoyants ordinaires solubles dans l'eau. Lorsque la température a atteint le niveau souhaite, l'armoire est prête à l'emploi.
Ne placez pas d'aliments ou autres au delà du rebord avant des étagères.
Si vous voulez garder la lumière sur, s'il vous plaît allumer le commutateur léger.

Entretien
Une couche de givre se formera peu à peu sur les parois de l'armoire. Lorsqu'elle atteind environ 3 cm d'épaisseur, retirez-la à l'aide d'un grattoir en plastique sans débrancher l'appareil. Celui-ci est de nouveau prêt à l'emploi. Si l'armoire est sale, debranchez-la afin de fair fondre la couche de givre et procédez ensuite au nettoyage.

L'unité dispose d'un condenseur qui peut recueillir de la poussière. La collecte de la poussière réduira la capacité de transférer et, finalement, d'endommager le compresseur. Le condenseur doit être nettoyé régulièrement par un technicien agréé.

Pannes
N.B. Si l'alimentation électrique a été coupée, rebranchez l'appareil après un laps de temps de 6 minutes. Dans le cas contraire, le compresseur ne pourrait pas redémarrer. L'armoire a été testée avant l'expédition. Toutefois, en cas de mauvais fonctionnement, nous vous prions de bien vouloir contrôler les points suivants:

1. L'alimentation électrique est-elle coupée?
2. Le fusible a-t-il sauté?
3. L'interrupteur est-il enclenché?
4. La fiche est-elle bien branchée?
5. La bouton du thermostat est-il réglé correctement?

Autre panes	**Contrôlez ce qui suit**
Le compresseur ne tourne pas	L'alimentation principale est-elle coupée? Le fusible a-t-il sauté? La prise est-elle connectee? La fiche est-elle bien en place?
La temperature est trop élevée	Le thermostat est-il correctement réglé? Le thermostat peut être reglé à une température plus basse en procédant comme décrit ci-dessus. La couche de givre est-elle trop épaisse?
Le compresseur tourne sans Interruption	Le thermostat est-il correctement réglé? Le régler comme indique précedemment. La température ambiante est-elle trop élevée? (Assurez une bonne circulation d'air autour de l'appareil).

Si après contrôl de tous les points ci-dessus l'appareil ne fonctionne toujours pas de manière satisfaisante, contactez un agent d'entretien agréé.

Remplacement de l'ampoule

ADVERTISSEMENT: Avant de remplacer l'amoule, débranchez l'alimentation électrique.

Destruction

Le propriétaire de l'appareil doit s'assurer que la destruction de celui-ci es effectuée en accord avec les exigences de sécurité et les normes relatives a la protection de l'environnement, à savoir: assurez-vous que les portes et les systèmes de verrouillages seront détruits indépendemment de l'appareil. Le système de refroidissement devra être démonté par un ingénieur frigoriste agréé. Les composants, produit réfrigérant et huile de compresseur inclus, seront déposés dans un centre de recyclage.

L'equipement est destiné à une utilization dans un environnement contrôlé et maintenu afin que la température ambiente n'excède typiquement pas 80°F (27°C).

Stajac Industries, Inc. dba Excellence Industries
500 South Falkenburg Road
Tampa, FL 33619
813-870-0340

Standard Warranty
Applies Only Within the Continental United States

Stajac Industries Warrants to the User
FIRST YEAR – The cabinet and all of its parts shall be free of defects in the material and workmanship under normal use and service for a period of one year from the date of installation. Stajac Industries' sole obligation under this warranty shall be limited, at its option, to either repairing or replacing any part of the cabinet determined by Stajac to be defective.

ADDITIONAL FOUR YEARS – The cabinet shall be free of insulation failures and refrigerant leaks within the insulated area of the cabinet for a period of five years from the date of installation or six years from the date of manufacture, whichever occurs first. Stajac's sole obligation under this warranty shall be limited, at its option, to either repairing or replacing any part of the cabinet determined by Stajac not to be as warranted.

The Stajac Standard Warranty and Compressor Warranty do not Cover
LABOR COSTS – Stajac shall not be responsible for any labor costs including but not limited to labor costs required to analyze the condition of the cabinet or its parts or labor costs incurred in the repair or replacement of any portion of the cabinet or its parts.

TRANSPORTATION COSTS – Stajac shall not be responsible for parts or assemblies which, upon inspection, are determined by Stajac to have been subjected to misuse, neglect, alteration, accident, abuse, damage during transit or delivery, or by fire or flood.

CONSEQUENTIAL DAMAGES – IN NO EVENT SHALL STAJAC BE LIABLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION, FOOD SPOILAGE OR PRODUCT SPOILAGE CLAIMS, NOR FOR ANY DELAY IN THE PERFORMANCE OF THIS WARRANTY DUE TO CAUSES BEYOND ITS CONTROL.

General
The standard warranty and any service contract related to the STANDARD WARRANTY shall apply only to the products sold and used within the boundaries of the Continental United States.

Users may file warranty claims either directly with Stajac or with immediate seller from whom the cabinet was purchased. All claims must be supported by information

concerning the alleged defect and specifically identified by the Serial Number of the cabinet.

THERE ARE NO OTHER WARRANTIES, EXPRESS, IMPLIED, OR STATUTORY, EXCEPT THIS WARRANTY, WHICH IS IN LIEU OF ALL OTHER WARRANTIES INCLUDING, TO THE EXTENT PERMITTED BY LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

FOUR-YEAR WARRANTY CONTRACT (OPTIONAL AT ADDITIONAL COSTS)

In addition to the Stajac Standard Warranty and in accord with the purchase of the optional Four-Year Compressor Contract, Stajac agrees to replace the compressor with a compressor of like or similar design and capacity if it is determined by Stajac that the compressor is inoperative due to defects in factory workmanship or material under normal use and service.

Stajac's obligation under the Four-Year Compressor Warranty Contract shall be limited to a period not to exceed five years from the date of installation. The Four-Year Compressor Warranty does not apply to any part of the cabinet or its finish, nor does it apply to the control relay fan or any electrical component.
Further terms of the contract cannot be considered valid if the compressor has been subjected to an accident, alteration, abuse, misuse, or damaged by flood, fire, or acts of God. The Standard Warranty and the Four-Year Compressor Warranty Contract shall place no liability on Stajac for any labor or labor costs in replacing the compressor, heat exchanger, drier, or replaceable parts of the cabinet. Stajac shall only be obligated to furnish the replacement compressor.

Do Not Drill Holes in Cabinet

Refrigeration tubing and wiring is routed through the cabinet walls. Leaks, wet insulation, or electrical problems caused by drilled holes are not covered by warranty.