CHEST FREEZER

INSTRUCTION MANUAL

MODEL: BD-11

BD-13

BD-16

BD-19

Excellence Industries

Profit from the Power of Partnership.

DearCustomer,

Please read these Operating Instructions carefully before you connect your new chest freezeras they contain important information on its safeand proper use, installation and care. Please keep the Operating Instructions in a safe place for future reference. Moreover, please pass them on to possible new owners of the appliance.

GeneralDescriptionofChest Freezer



BD-11/13/16/19

1.Lid	2.Basket
3.Cabinet	4.Compressor cover
5.Wires	6.Green light
7.Thermostat Knob	8.Lock
9.Foot wheel	

Note:Theabovestructurediagramisforreferenceonly,prevailin kindifthereexistsanydiscrepancy.

Transportation and Installation



1. When you transport the freezer, the angle between the compartment body and the ground should be no more than 45°,and you should never place the freezer up-side down.
2. Do not use any of the external part as loadingpoints, for example, the condenser on the back, the door or the hinge.
3. When the freezer is installed or used, all the package (including boardand foam plastic) should be got rid of.
4. Keeping the freezer stable to avoid vibration and noise.
5. The freezer should be installed in the place with good ventilation, a space of at least 10cm should be allowed between the surrounding walls and the cabinet wall for air condition.
6. It should be placed far from heating resource and not under direct sunshine to avoid decrease of the efficiency of refrigeration.
7. Install the freezer in a dry place so as to prevent rust on the compartment body, which may affect the electric insulation.

Cautions

1. The freezer must be connected with earth correctly, never with the heating pipe and coal gas pipe.
2. Make sure of grounding.
Consult a qualified electrician or service person if the grounding instructions are not completely understood, or if you have doubts on whether the appliance is properly grounded.The incorrect grounding may cause breakdown and electric shock.
3. In case of any damage on the electric wires and plug, please contact the after-sale service and never do it yourself.When plug out, please take the plug, not the wires.
4. It is not recommended to use any extension cords.
5. If the voltage is unstable, please choose the suitable automatic voltage regulator.
6. Connection the power to check the freezer before using, the freezer can be used until the temperature decreases obviously after 30 minutes.
7. You should adjust the temperature control according to the requested temperature and quantity of the stored food and the environmental temperature.

8. Before putting the stuff into the freezer please adjust the temperature control to the lowest point and let it work till the temperature of inner cabinet decreases to -18℃and then putting the stuff in, after 12 hours adjust the temperature control to the normal point.
9. Never put hot food in the freezer directly only after it has been cooled naturally outside.
10. The stuff should be put into the freezer partially, each lot will not be more than the figure which is equal to the capacity(L) divide by 20.
11. Not full the freezer and make it crowded, big meat should be divided into several small parts.There should be reasonable space between the foods for better freezing.
12. If power cut off is needed, you should wait for at least 5 minutes before turn on again to avoid damage to the compressor.
13. The stuff stored should be packed with plastic bag well to avoid smell-mixed and moisture-lost, and reduce the frost at the small time.
14. Never store any flammable, explosive and corrosive liquid or gas in the freezer and keep it away from them.
15. Beer, beverage, fresh flower, medicine and injections can not be put into the freezer.
16. Please make the temperature control to the lowest point if you want to store ice cream or other uneasy-frozen food.
17. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
18. Children shall not play with the appliance.
19. Cleaning and user maintenance shall not be made by children without supervision.
20. If your freezer is with lock, to avoid children shut into the freezer, do not leave the key near the refrigerator or other place easy to be touched by children.
21. Do not damage the refrigerant circuit.
22. If the appliance cannot be used any more, please release the refrigerant before abandon at a place exposed to the air and away from tinderbox.
23. Freezer discarded after the need for disposal according to local laws and regulation.
24. Keep ventilation openings in the equipment enclosure or in the built-in structure, must be free from obstruction.

CorrectDisposalofthisproduct

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased.They can take this product for environmental safe recycling.

The Function of Control Panel

1. The figure on the temperature control 1~8only means the temperature level from high to low, not meansthe špecific temperature, turn the knob clockwise, the temperature inside will go down, turn the knob to the other direction, the temperature will go up.
2. It suggests to adjust thethermostat knobto "5"when you store the foods.
3. The green light is a power indicator,when it is on, thepower isconnected.



BD-11/13/16/19

Before Using

1.Remove all packages, including the foam backing at the bottom of chest freezer and the tapes fixing accessories in the box.
2.Place the chest freezer to a proper position, and adjust the feet to lever. It is better to clean the chest freezer before use.
3.Place the chest freezer and adjust to lever, clean it, let the chest freezer stand for above 30 minutes, and then power on to ensure that the chest freezer can operate normally.

Defrost

1. Defrost when the frost thickness on the wall of the cabinet reaches 5mm to optimize the freezing capacity.
2. Turn the temperature control to the lowest point for 5-6 hours before defrosting.
3. Cut off the power and take out the food, use the defrost removal, do not apply sharp tools.
4. After defrosting, clean the wall with dry cloth, and then power on.
5. Donotuse mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

Maintenance and Cleanness

1. Do not open the door frequently and too long to save energy.
2. Never leave heavy or hot stuff on the top of the freezer to avoid deforming.
3. Cut off the power before cleaning.
4. To clean the freezer, please use soft cloth dampened in some moderate detergent and hot water.
5. Use warm water to clean oil or fruit juice stain on the magnetic gasket in order to keep its elasticity.Apply some talcum powder to it to prolong its service life.
6. The freezer should not be left unused for a long time, to stop using the freezer, disconnect the main power first, then clean the inside and leave the door open for 2~3 days to dry it。

The Following Phenomena are Normal:

1. There will be sound of flowing water when the refrigerant is running.
2. The frozen food do not melt even if a long time power off.
3. When the environment humidity is too high, there will be dew condensed on the surface of the freezer.
4. When the machine is running, the condenser and compressor will be hot.

Trouble Shooting

	REASON	SOLUTION
Unfreezing	*Temperaturecontrolison the highest point	Adjust the temperature
	*Plugandoutletnot connected well	Make them connect well
	*Fusebrokenoff	Change the fuse
Compressor cannot stop working	*Temperaturecontrolison the lowest point	Adjust temperature control
	*Toomuchstuffstoredin one time	Reduce the quantity
	*Thickfrost	Defrost
	*Toomuchtimesof door-opening	Reduce the times of door-opening
	*Toonearthewall	Far from the wall
	*Nearthehotsourceorsun	Change the place
Big noise	*Groundisnotflat	Change the place
	*Refrigeratingtubes connected	Separate them

EMARK: If you cannot solve the troubles according to the above- mentioned ways, please contactthe after-sale service, do not handle it by yourself.

ATTENTION

- We have a policy of continuous improvement on our products and reserve the right to change materials and specifications without notice. To confirm the specific parameters, please according to the rated label on the product.
- The refrigerant inside is explosive type. Once malfunction occurs, it must be repaired by professional person. Do not handle it by yourself。

Excellence Commercial Products
Division of Stajac Industries
500 South Falkenburg Road
Tampa, FL 33619,U.S.A
Tel:813-870-0340

Installation manual of latch hook

1. Take off the gummed tape covered on the hole.

2. Make the latch hook aimed at hole and fix it with two screws.

3. Installation of latch hook is finished.

Installation manual for handle

Step 1: Fix the handle on the door with four screws.

Step 2: Insert the one side of handle cover into the handle pedestal.

Step 3: Insert the other side of handle cover into the handle pedestal.

Step 4: Press the cover into the handle pedestal.